

Instructions for magnet exchange in the Vintage Vibe Guitars SP-90 pickup



1. Access the back of the SP-90 pickup and use a small Phillip's drive screwdriver to remove the three machine screws on the bottom.



2. Remove the magnet cover plate and set aside; carefully pry the magnets from the base of the pickup. Note magnet orientation.



3. Remove the black tape from the original magnets and transfer to the new magnets.



4. The new magnets will be installed with the black tape between the magnet and the bottom of the pickup body.



5. Make sure the two magnet bars of the new magnet assembly are aligned with each other and the orientation is correct.



6. Re-install the cover using the three machine screws. Carefully store the original magnets.

www.vintagevibeguitars.com

Vintage Vibe Guitars 2009

All Rights Reserved

email: vintagevibeguitars@gorge.net

Phone: (541) 436-2836 [Pacific Standard Time]